Dive Pitch Shifter Quick Start

KLOWRA

@KLOWRA_PEDALS
WWW.KLOWRA.COM
SERVICE@KLOWRA.COM

QUICK START

KLOWRA

DIVE PITCH SHIFTER

1 DROP A/B
Select pitch interval for **DROP A** (White LED) / **DROP B** (Purple LED).

2 MIX
A Adjust the ratio of dry and wet signals.

3 GLIDE ATK
Adjust the attack time when engaging the effect, and the attack time for pitch switching.

4 GLIDE RLS
Holding the button while rotating the **GLIDE ATK** knob to set the Glide Release time.
Adjust the release time when engaging the effect, and the release time for pitch switching. The LED flashes yellow rapidly to confirm the adjustment.

5 CTRL
External TS Footswitch Input.

6 Toggle Switch and Footswitch Logic
The toggle switch determines the transition between **DROP A and DROP B**, and defines the footswitch operation logic.

L- Latch Mode
Press the footswitch to turn the effect on or off. Holding the footswitch to switch between **DROP A and DROP B**.

A/B - A/B Mode
Press the footswitch turns the effect on, or toggles between **DROP A and DROP B** if the effect is already active. Holding turns it off.

M - Momentary Mode
When the effect is off, holding the footswitch momentarily engages the effect. When the effect is on, holding the footswitch momentarily turns it off.

ADAPTER: 9V ⎓ 150mA POLARITY: ⊖-◐-⊕
Connect to 9V DC, center negative power supply, 150mA minimum.
NOTE: If the power supply is insufficient, it may cause malfunction.
We recommend isolatedpower supply for your daily operation.