# South Zoo Vocal Synth Quick Start

KLOWRA

@KLOWRA_PEDALS
WWW.KLOWRA.COM
SERVICE@KLOWRA.COM

## QUICK START

KLOWRA

### SOUTH ZOO VOCAL SYNTH

**1 TAILS**
Adjust the tails of the animal voice.

**2 MIX**
Adjust the mix level between the guitar signal and the animal voice.

**3 SPEED**
Adjust the speed of the animal voice.

**4 DETAIL**
Adjust the details of the animal voice.

**5 Voice Button**
Click the button to switch between three animal sounds:

○ CAT ● FROG ● HORSE

**6 Toggle Switch & Footswitch Hold Functions**
The toggle switch selects the Animal Singing Mode and assigns the specific effect triggered by holding the footswitch. LED turns Purple when engaged.

⇄ Pitch Follow
HOLD: Inverted Pitch Follow.

≈ Normal
HOLD: Freeze the current animal sound and randomize the **SPEED** parameter.

⇄ Normal
HOLD: Freeze the current animal sound and randomize the **TAILS** parameter.

**7 CTRL**
External TS Footswitch Input.

ADAPTER: 9V ⎓ 150mA POLARITY:
Connect to 9V DC, center negative power supply, 150mA minimum.
NOTE: If the power supply is insufficient, it may cause malfunction.
We recommend isolatedpower supply for your daily operation.