GLX®

a division of galaxy industries

SD-100 SOFT DISTORTION

SD-100 SOFT DISTORTION

OWNER'S MANUAL

INSTRUCTIONS

Thanks for purchasing our product. In order to make the best use of your SD-100, please read the following carefully.

FEATURES

The SD-100 is equipped with dual gain circuitry. It offers a warm and soft distortion sound. Set the SUSTAIN to create long sustain. This SOFT DISTORTION is a totally new pedal effect for guitarists.

BATTERY REPLACEMENT

1. Loosen the screw on the pedal to open it.
2. Remove the battery from the battery compartment and disconnect the battery cable.
3. Connect a new battery to the battery cable and put it back in the battery compartment. Make sure that the polarity of the battery is correct and the battery cable does not interfere with the spring or pedal cover.
4. Push the coil spring into the spring base and close the pedal.
5. Insert the thumb screw into the guide bush hole and firmly tighten the screw.



IMPORTANT NOTES

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Do not use this apparatus near water.
5. Clean only with dry cloth.
6. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
7. Do not install near any heat sources such as radiators, heat registers, stoves or any other apparatus (including amplifiers) that create heat.
8. WARNING: to reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
9. Protect the power cord from being walked on or being pinched.
10. Unplug this apparatus when unused for long periods of time.
11. There are no user serviceable parts inside. All servicing has to be done by qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power supply cord or plug is damaged, when liquid has been spilled or objects have fallen into the apparatus, when the apparatus has been exposed to rain or moisture, when the apparatus does not operate normally or when it has been dropped.

PANEL DESCRIPTION

1. AC Adaptor Jack: Connect an AC adaptor (100-140V/50-60Hz).
   An AC adaptor allows long and secure operation without worrying about battery life.
   Use the proper supply for your area's Mains line voltage.
2. Indicator LED: This LED indicates when the effect is turned on.
   - Operating on battery power only: when the LED becomes dim or does not light the battery needs to be replaced.
3. Level Knob: Use this control to adjust the level of the effect sound.
4. Low Knob: Use this control to adjust the low frequency of distortion. Turn this knob clockwise to emphasize low frequencies and create a tight and thick distortion.
5. High Knob: Use this control to adjust the high frequency of distortion. Turn this knob clockwise to emphasize high frequencies and create a clear and sharp distortion.
6. Sustain Knob: Use this control to sustain the distortion. Turn this knob clockwise to lengthen the distortion sound and counter-clockwise to shorten it.
7. Dist Knob: Use this control to boost or cut the distortion. Turn this knob clockwise to increase the distortion sound and counter-clockwise to decrease the distortion sound.
8. Output Jack: Use this jack to connect an amplifier or other units for mono output.
9. Pedal: Press the pedal to turn the effect on and off.
10. Thumb Screw: Loosen the screw to open the pedal for battery replacement. (For details of the battery replacement, see "BATTERY REPLACEMENT")
11. Input Jack: Connect your instrument to this jack. To prolong battery life, disconnect all cables from the pedal when it's not in use.

SPECIFICATIONS

Normal Input Level	-20 dBu
Input Impedance	1MΩ
Normal Output level	-20 dBu
Output impedance	1kΩ
Recommended Load Impedance	10kΩ or greater
Residual Noise	-100dBu (IHF-A, Typ.)
Power Supply	DC 9V; Dry Battery (6F22/9V), AC adaptor
Connections	Input, Output, AC Adaptor
Controls	Pedal Switch, Level, Low, High, Sustain, Dist
Indicator	Check indicator (serves also as battery check indicator)
Current Draw	18mA, (DC 9V)
Dimensions	72*128*60 mm.
Weight	406g (no battery)
Option	AC adaptor

a division of galaxy industries



CONNECTIONS

1. Connecting an instrument to this jack will automatically switch the unit on. Be sure to disconnect the cord from this jack when the unit is not being used.
2. Before connecting or disconnecting any instrument, make sure that the volume of the amplifier is turned down.
3. The output jack is to connect an amplifier or other units for mono use. Both the dry and processed signals are output.